

BODY AND INTERIOR COMPONENTS

INTERIOR continued

COMPONENT	P.N.C.	GOLD PREFERRED		SILVER PREFERRED			BRONZE			PREOWNED PREFER.		PREOWNED PLUS					
		RC	NC	RB	NB	NA	RM	NN	NL	RC	NC	RB	NB	NA	RM	NN	NL
SEAT BELT LIMIT SWITCH	86970	•	•														
SEAT BELT LIMIT SWITCH	86980	•	•														
SWITCH-SEAT SLIDE	86982	•	•														
SWITCH ASSY-THIGH SUPPORT	87011	•	•	•	•				•	•	•						
SWITCH - SEAT BACK TILT	87017	•	•	•	•				•	•	•						
SWITCH - SEAT BACK TILT CANCEL	87018	•	•	•	•				•	•	•						
HARNES-FRONT SEAT	87019	•	•	•	•				•	•	•						
SIDE AIRBAG HARNES	87020	•	•														
BACK VIBRATOR PLATE	87060	•	•														
CUSHION VIBRATOR PLATE	87080	•	•														
SEAT AIR CONTROL SWITCH	87106	•	•	•	•				•	•	•						
MOTOR ASSY-FAN	87305	•	•	•	•				•	•	•						
UNIT-FAN MOTOR CONTROL	87306	•	•	•	•				•	•	•						
UNIT-HEAT SEAT/THERMOSTAT	87345	•	•	•	•				•	•	•						
SLIDE, LIFT SWITCH (PWR/SEAT)	87352	•	•														
WIRE ASSY-RECLINING DEVICE	87403	•	•	•	•				•	•	•						
SPECIAL BOLT	87408	•	•														
FRT. SEAT LIMIT SWITCH	87504	•	•														
AIR PUMP	87652	•	•														
SLIDE ASSY (PWR/SEAT)	87653	•	•	•	•				•	•	•						
LIFT ASSY (PWR/SEAT)	87654	•	•	•	•				•	•	•						
ELECTRIC RECLINING DEVICE ASSY	87655	•	•	•	•				•	•	•						
LEVER-LUMBAR SUPPORT	87692	•	•	•	•				•	•	•						
ACTUATOR ASSY-REAR SEAT, R	88049	•	•														
FRAME&POWER UNIT-REAR SEAT	88060	•	•														
SEAT SWIVEL ASSY	88201	•	•														
2ND SEAT BACK HINGE	88350	•	•														
REAR RECLINING DEVICE ASSY	88451	•	•														
2ND SEAT SLIDE	88501	•	•														
SLIDE ASSY.—3RD SEAT	88505	•	•														
MOTOR ASSY-REAR SEAT	88510	•	•	•	•				•	•	•						
REAR SEAT BACK LOCK	88603	•	•														
REAR SEAT BACK STRIKER	88604	•	•														
HANDLE & CABLE-3RD SEAT	89045	•	•														
HINGE - 3RD SEAT LOWER	89130	•	•														
CABLE-SEAT LOCK	89200	•	•														
CABLE-HEAD REST, RELEASE	89201	•	•														
CABLE-SEAT BACK, RELEASE	89202	•	•														
3RD SEAT HINGE ASSY	89303	•	•	•	•				•	•	•						
SEAT LOCK ASSY	89341	•	•														
LOCK ASSY—2ND SEAT	89342	•	•	•	•				•	•	•						
LEVER LOCK-3RD SEAT	89344	•	•														
LOCK ASSY-3RD SEAT	89391	•	•														
RECLINING DEVICE ASSY	89401	•	•	•	•				•	•	•						
LATCH ASSY - 3RD SEAT	89451	•	•														
RAIL ASSY—3RD SEAT	89552	•	•	•	•				•	•	•						
HOOK-3RD SEAT	89920	•	•														•
STRIP, PINCH, BACK DOOR	90523	•	•														
TAILGATE WEDGE/DOVETAIL	90623	•	•														
TAILGATE HANDLE	90940	•	•														•
SUN ROOF RAIL ASSY	91350	•	•														
ELECTRIC DOOR MIRROR	96302	•	•	•	•												
ACTUATOR MIRROR	96367	•	•	•	•												
A/T RANGE INDICATOR	96940	•	•	•	•				•	•	•						
ASSIST AIRBAG MODULE	98515	•	•	•	•				•	•	•						
AIRBAG MODULE	98520	•	•	•	•				•	•	•						
SIDE AIRBAG MODULE ASSY	98830	•	•														

INTERIOR continued

COMPONENT	P.N.C.	GOLD PREFERRED		SILVER PREFERRED			BRONZE			PREOWNED PREFER.		PREOWNED PLUS					
		RC	NC	RB	NB	NA	RM	NN	NL	RC	NC	RB	NB	NA	RM	NN	NL
AIRBAG ON/OFF SWITCH	98840	•	•	•	•				•	•	•						
AIRBAG ON/OFF SWITCH HARNESS	98841	•	•	•	•				•	•	•						
MODULE ASSY-AIR BAG PRESSURE DETECTION	98850	•	•	•	•				•	•	•						

BODY AND INTERIOR COMPONENTS

AUDIO / NAVIGATION / MOBILE ENTERTAINMENT

COMPONENT	P.N.C.	GOLD PREFERRED		GOLD		SILVER PREFERRED		SILVER		BRONZE		PREOWNED PREFER.		PREOWNED PLUS		PREOWNED	
		RC	NC	RB	NB	NA	RM	NN	NL								

AUDIO / NAVIGATION / MOBILE ENTERTAINMENT

REAR WINDOW ANTENNA AMP**	25190	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
RELAY-AUDIO AMP	25198	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
NAVI SPEAKER RELAY	25273	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
NAVI GPS ANTENNA ASSY	25957	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CABLE-GPS ANTENNA FEEDER	27531	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONTROL ASSY-IT MASTER	25914	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SPEAKER**	27933	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SPEAKER - WOOFER**	27934	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CABLE-AUX AUDIO SYSTEM	27946	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ANTENNA	27960	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONDENSER	27984	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
RADIO FINISHER**	28041	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
TUNER ASSY - AV	28050	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
PRE-AMP SPEAKER AMP**	28060	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
AMPLIFIER UNIT - PRE MAIN	28061	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
POWER SUPPLY BOX**	28089	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
VIDEO OR NAVI DISPLAY ASSY	28090	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
FES Video Monitor***	28091	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
MOTOR ASSY - DISPLAY	28092	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
DISPLAY ASSY-INTEGRATED	28094	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
MAGAZINE-CD	28118	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
DVD UNIT**	28119	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SWITCH ASSY-DISK EJECT	28123	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
TWEETER-RR DOOR	28138	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
BOX-SPEAKER	28170	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
BOX - FR SPEAKER	28172	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
GRILLE - FR SIDE SPEAKER	28176	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CHANGER-CD AUTO	28184	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
RADIO/RADIO WITH CD	28185	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ANT ASSY-SAT	28208	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ANTENNA ROD/MAST**	28215	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SAT ANTENNA ASSY	28228	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SMART ENTRANCE ANTENNA ASSY	28242	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
FEEDER ASSY - ANTENNA	28243	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
FEEDER ASSY (TEL ADPTR/BLUE TOOTH)-ANTENNA	28245	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ANTENNA-ADAPTOR	28247	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONTROL PANEL-FES	28259	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONTROL ASSY-BACK VIEW	28262	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SWITCH-REMOCON	28267	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
REMOTE RADIO SWITCH**	28268	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
PHONE-HEAD	28310	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
UNIT-MICROPHONE MIXING	28312	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONTROL ASSY-AUDIO VISUAL	28330	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONTROL UNIT ASSY-DISPLAY	28332	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
UNIT-ADAPTER (BLUE TOOTH), TEL	28338	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
TRANSFER ASSY - NAVI	28344	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
BONDING (GROUNDING) WIRE**	28360	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SWITCH ASSY-ITS & AUDIO	28394	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
NAVI SWITCH ASSY	28396	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
AV/NAVI SWITCH ASSY	28397	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONTROL UNIT-AUX AUDIO SYSTEM	28411	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONNECTOR-AUX AUDIO SYSTEM	28413	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONT ASSY CAMERA	28416	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•

AUDIO / NAVIGATION / MOBILE ENTERTAINMENT continued

COMPONENT	P.N.C.	GOLD PREFERRED		GOLD		SILVER PREFERRED		SILVER		BRONZE		PREOWNED PREFER.		PREOWNED PLUS		PREOWNED	
		RC	NC	RB	NB	NA	RM	NN	NL								

CAMERA ASSY-SIDE VIEW	28419	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
AMPL-HEADPHONE	28438	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CAMERA ASSY-BACK VIEW	28442	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CONTROL ASSY-STATUS RECORDER	25466	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CAMERA ASSY-FR VIEW	28461	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
FES Video Cassette Player***	28706	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CASSETTE PLAYER/DECK	29200	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
BALANCER-SOUND	29350	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CLARION AUDIO/COMBO UNIT**	2790A	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
HITACHI CASSETTE DECK	2790B	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
PANASONIC AUDIO/COMBO UNIT**	2790C	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ELD (QUEST) RADIO/COMBO UNIT	2790F	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
BOSE SPEAKER**	2793A	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CLARION SPEAKER AMP**	2806C	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ELD (QUEST)SPKR AMP NS	2806F	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SPEAKER - WOOFER**	2806H	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
PANASONIC (QST) SPKR AMP	2806P	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SONY SPKR AMP	2806S	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CLARION CD PLAYER	2818A	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
PANASONIC CD PLAYER**	2818C	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SONY CD PLAYER**	2818D	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ALPINE CD PLAYER	2818E	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ELD(QST)CD PLAYER	2818F	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CLARION CASSETTE DECK	2920A	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
HITACHI CASSETTE DECK	2920B	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
PANASONIC CASSETTE DECK**	2920C	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
MOBILE ENT SYS***	AA018	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
AV TUNER/SAT	AA055	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
CD CHANGER CARTRIDGE**	B8118	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•

**Coverage applicable only to policies sold on or after April 1, 2003

***Covered Mobile Entertainment System Components listed herein are applicable to Preferred Plans sold on or after April 1, 2004.